ZB2935

Floor Care & Small Appliances

RRP AUS $219.95
Ergorapido™ 2 in 1 with Brush Roll Clean™ Technology. Cordless Freedom for Ultimate Flexibility.

FEATURES

CORDLESS FREEDOM

A 12 volt Ni-MH battery gives you instant grab and go cleaning for up to 20 minutes, no cords, no fuss.

BRUSH ROLL CLEAN

This innovative feature is designed to shear off hair, string and debris that build up on the brush roll, all with the push of a button.

LED LIGHTS ON NOZZLE

LED headlights help see under furniture and in dark spaces, making sure you never miss a thing.

2 IN 1 CLEANING

Convenient Mini-upright and hand-held in one

ERGONOMIC & MANEUVERABLE

A double jointed floor nozzle makes Ergorapido super easy to manoeuvre in and around tight spaces.

BENEFITS

CORDLESS FREEDOM

Imagine being able to suck up those spills around the home that usually have to wait until the regular vacuum comes out. Ergorapido lets you do just that, no cords, no assembly and in almost no time at all!

BRUSH ROLL CLEAN

Brush Roll Clean allows for effortless removal of hair, string and other debris that build up on the brush roll, without getting your hands dirty.

LED LIGHTS ON NOZZLE

Never miss those patches of dust and dirt under the couch or in other dark spaces of your home.

2 IN 1 CLEANING

Clean both under and over the floor with the easy to release hand held unit, perfect for benches, shelves and table tops.

ERGONOMIC & MANEUVERABLE

Get the job done fast, without having to battle with your furniture.

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes theproducts that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours ofproducts illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This appliance is warranted against manufacturing defects in Australia and New Zealand for 24 months following the date of original purchase of the Appliance, where the Appliance is used for personal, domestic or household use (i.e. normal single family use) as set out in the instruction manual. Where the Appliance and accessories (including nozzles, brushes or other cleaning attachments) are used for commercial purposes, the Appliance will then be warranted against manufacturing defects in Australia for 3 months and in New Zealand for 3 months, following the date of original purchase of the Appliance.

ELECTROLUX FLOOR CARE & SMALL APPLIANCES AUSTRALIA

telephone: 1300 366 366
fax: 1800 673 326
email: info@electrolux.com.au
web: www.electrolux.com.au

ELECTROLUX FLOOR CARE & SMALL APPLIANCES NEW ZEALAND

telephone: 05 08 730 730
fax: 09 573 2382
email: floor.care@electrolux.co.nz
web: www.electrolux.co.nz